

CONNYP IP68 QUICK CONNECYOR



EN	Installation Instructions	IT	Istuzioni di montaggio
DE	Montageanleitung	LT	Montavimo Instrukcijos
CZ	Montážní návod	LV	Instalācijas instrukcija
DK	Monteringsvejledning	NO	Monteringsanvisning
EE	Paigaldusjuhend	PL	Instrukcja montażu
FI	Asennusohje	SE	Installationsanvisning
FR	Notice de montage	RU	Инструкция по монтажу
HU	Szerelési útmutató	SRB	Instrukcija za instalaciju
HR	Uputstvo za montažu	SK	Montážny návod
NL	Montagehandleiding	SLO	Navodilo za montažo
RO	Instructiuni de montaj	CN	安装说明书

NOTE

- This component may only be installed, operated or maintained by qualified personnel.
- Operating personnel must have read and understood these instructions.
- Related technical information is available at: www.wieland-electric.com

CAUTION

- A locking device is required for DIN EN 61535 approval. IEC 61535 conformity does not automatically exclude the danger of confusion with installation plug connector systems from the same manufacturer!
- Installation plug connector systems are no substitute for national plug/outlet systems for domestic use.
- To maintain the IP- and NEMA-rating type of enclosure, protective caps (accessory) must be mounted on all unoccupied connectors!
- The connectors must not be exposed to bending forces (e.g. do not attach loads to the cable, no free-dangling cable windings etc.).
- Observe the country-specific regulations for installation.
- The connectors are not suitable for current interrupting. Never connect or disconnect under load!

WARNING

When using connectors with contact sealing, use only one connector with contact sealing – either male or female connector.

Bemessungsdaten / Rated values

Bemessungsstrom / Rated current	16A
---------------------------------	-----

